



Z H O N E™


# 1512-A1 ADSL2+ Router Quick Installation Instructions

Document Number 830-02111-01

July 2010

## Installation

- 1 Turn off the router and any devices you will attach to the router by disconnecting the power cord from the modem.
- 2 Connect the DSL line to the DSL jack using the provided RJ11 cable. The DSL WAN line connection is configured for connection by default.
- 3 Connect PCs, hubs, and switches to the LAN ports. Either a straight-through Ethernet cable (provided) or a crossover cable can be used. The router automatically determines the type of signal required.
- 4 Attach the power adapter. The supplied power adapter may look different than the one illustrated here.
- 5 Turn on the router and any devices you have attached to it.
- 6 You need to configure your router to communicate with wireless devices. For more information see the user's guide on the CD which comes with the unit (or download from the web site). The router is configured by default to communicate with devices on the LAN ports.



**NOTE:** Slots and openings in the cabinet are provided for ventilation. To ensure reliable operation of the product and to protect it from overheating, these slots and openings must not be blocked or covered. This unit is also certified to operate effectively under the following conditions: Operating Temperature: 32° F to 104° F (0° C to 40° C).

See the User's Guide on the Zhone website for important safety instructions and more information. Go to [www.zhone.com](http://www.zhone.com) (Registration required) and select: *Service & Support - Documentation - DSL Bridges and Routers*.

